

# Wltoys V303 RC 2.4G GPS Quadcopter الباحث Quadrocopter

## المنتج وظائف

1. السيارات التجريبية وظيفه GPS.
2. الطول. GPS التحكم مجلس مراقبة الطيران.
3. وضع الخطوط الرأس (عادة، والاتجاه إلى الأمام لتعلق متعددة الدوار هو نفس الاتجاه الأنف. باستخدام CF 3. ووض الخطوط أينما نقاط الأنف، والاتجاه إلى الأمام له علاقة مع الاتجاه الأنف شيء : في الوقت، (IOC) التحكم في التوجيه الذكي قفل الطيران، والاتجاه إلى الأمام هو نفس اتجاه الأنف سجلت في قفل المنزل الطيران، والاتجاه إلى الأمام هو نفس الاتجاه من وجهة موطننا لعدة الدوار).
4. مماثلة كما اسهم الشركات الامريكية الكبرى فانوم UVA السيارات باثفايندر 4G. مفتاح واحد الذهاب الرئيسية (2.4 P يمكن إضافتها). P أمبير؛ 1080 & P كاميرا فيديو 720
5. المأمونة الجانب وأمبير. السيارات التنقل الوطن / هبوط (عندما يتم قطع الاتصال بين المراقب المالي الرئيسية هي GPS والارسال، ومخرجات كل العصي الأمر من وحدة التحكم سوف تذهب إلى موقف وسط. إذا كانت إشارة جيدة بما فيه الكفاية، ونظام الزناد في العودة إلى ديارهم تلقائيا وسوف الهبوط بسلام
6. أحمر يومض لتحذيرك. في LED مستويين من حماية الجهد المنخفض (في المستوى الأول من الحماية، ومؤشر (الطبقة الثانية من نظام الحماية تلقائيا بتشغيل وظيفه العودة







FIXED POINT AND HEIGHT  
WITHOUT CONTROLLING






## HEADING LOCK MODE

Open the heading lock switch the headless mode is turned on

## AUTO-RETURN FUNCTION

When the explorer beyond the range, the system automatically start its protection function protection aircraft safely return



AUTO-RETURN



AUTO-RETURN BY CLOSING THE REMOTE CONTROL



SUPER CAPACITY BATTERY



POWERFUL MOTOR



FLASHING LAMP



**NAVIGATION LAMP**

## BASIC PARTS LIST



QUADROCOPTER SEEKEY



TRANSMITTER



PROPELLER



PLUG



USB DATA CABLE



BATTERY



CHARGER



CAMERA ( IN ADDITION TO BUY )



OTHER PARTS



CAMERA FRAME

**PRODUCT DETAILS**



**ADVANCED MATERIAL**



**PROPELLER**



**UNIQUE APPEARANCE**



**SKID LANDING GEAR**



**FLASH LED**



**MICRO-CAMERA**



**OUTDOOR SENCE**



**QUADROCOPTER SEEKEY**





## PRODUCT STRUCTURE



---

**PROPELLER**

**FUSELAGE ABDOMINAL**

**LED FLYING INDICATOR**

**USB SOCKET**

**WIFI SOCKET**

**MAGNETIC SENSOR**

**BOTTOM**

## REMOTE CONTROL INSTRUCTION



### RC BATTERY BOX

Put the 4 batteries into the battery box in the correct way, and then cover the battery cover.

## ASSEMBLY INSTRUCTIONS

### INSTALL THE BLADES



**STEP 1** Take down the propeller hoop on the motor first



**STEP 2** Make sure the rotating direction of the blades should be the same as the rotating direction of the motor



**STEP 3** Put the propeller hoop on the blade



**STEP 4** Insert one round stick into the hole of the propeller hoop, Reverse rotation arrow

## INSTALL THE BATTERY



**STEP 1** Hold the battery cover and pull out



**STEP 2** Put the battery into battery compartments



**STEP 3** Connect the battery and the power wires



**STEP 4** Cover the battery cover

## INSTALL THE CAMERA



**GOPRO 3 CAMERA**  
NEED TO BUY IT BY YOURSELF

IT CAN NOT BE LOADED ANY OTHER  
CAMERAS IN THE MARKET



## THE INSTALLATION OF THE CAMERA FRAMES



## INSTALL THE CAMERA FRAME TO THE BOTTOM OF THE AIRCRAFT



## INSTALL THE CAMERA TO THE CAMERA FRAME



المواصفات

11.1 (شمل) V 2700mAh 25C المنتج البطارية:  
(غير المدرجة) AA راديو البطارية: 6 \* 1.5  
950 2212 / KV×4PCS المحرك:  
الارسال عن بعد: 500 متر  
hours الشحن الوقت: 1.5-2  
Mins وقت اللعب: 13-15

## قائمة التعبئة

- 1 × quadcopter
- 1 × اللون يو
- 1 × الراديو
- 1 × دليل
- 1 × التوازن شاحن
- 4 × شفرة
- 1 × بطارية ليو
- 1 × USB
- 1 × عرافة وجع
- 1 × (الكاميرا جيل GOPRO) جيمبل

□□□ □□□□□□ □□□□□□ □□□□□□.

**MORE PRODUCTS!**