

Parametri del prodotto:

1. prodotto dimensioni (cm):17.5 * 17.5 * 4.8
2. colore scatola dimensioni (cm):36.5 * 24 * 7,8
3. prodotto colore: rosso/giallo /Blue
- 4.Playtime(minute): > 5.5
5. controllo a distanza (metri): 30-50
6. prodotto batteria: 3.7 v 600mAh LI-PO
7. controller batteria: AA * 3 non incluso
8. charging tempo (minuti): 40-60
- 9.Wheelbase (mm):9.2 * 9.2

Parti di ricambio □

lame * 1, manuale dell'utente * 1, cavo USB * 1, cacciavite * 1


Descrizione del prodotto:

1. 3D lanciante
2. senza testa modalità
3. una chiave di ritorno
4. avanti, indietro, girare a sinistra/destra,
sinistra/destra lato volare, su/giù
5. blocco
6. LED

One key return

A key home easily, fear lost

3D flipping headless mode one key return forward/backward, turn left/right, side flying, up/down building block
USB Spare-parts Model*1 user manual*1, USB USB Spare-parts Model*1 user manual*1, USB



Headless mode

Don't need to tell direction, easy to recall

3D flipping headless mode one key return forward/backward, turn left/right, side flying, up/down building block
USB Spare-parts Model*1 user manual*1, USB



Cool 3D flipping

Cool 3 d flipping, novice, expert can play

3D flipping headless mode one key return forward/backward, turn left/right, side flying, up/down building block
USB Spare-parts Model*1 user manual*1, USB



