

2.4G 3.5CH RC HELICOPTER WITH GYRO REH28997

Feature

Misty & bright LED lights, New table controller with sound

Built-in gyro offers the helicopter a nimble and stable flight;

The display lights and flashing words can be toggled on/off by transmitter


Adjustable control speed: High and Low.

Function: up/down, forward/backward, left/right, Gyro, simulation sound& shake, demo.

2.4Ghz Transmission technology



1. Please read the instruction manual carefully before operating the product.
2. Ensure the helicopter be operated indoors.
3. Keep batteries away from fire or high temperature environment.
4. When operating the helicopter, keep it 1–12 meters away from the player or others to avoid injury in case of collision.
5. Do not decompose or modify the product which may cause malfunction and accident.
6. Fly the helicopter within your eye vision and safety control.
7. Need the adult supervision once the helicopter is being playing by the children.
8. Should be charged by the original USB cable, and charging time shall be about 50 minutes.
9. Only batteries of the same or equivalent type that recommended can be used. Do not mix the new and old batteries.
10. Do not touch the heating motor components that avoid scald.



► Product display


Black



Red



01 anti-wrestling



02 Automatic cruise



03 High and low speed flight mode




04 light switch



05 control performance is strong



► Product details




01 Sleep mode

02 toughness of the balance bar



03 Imported gyroscope



04 charging socket



05 High quality speaker



06 gunfire sound effects



Specifications

Charging Time : About 50 minutes

Flying Time : About 7-8 minutes

Controlling Distance: About 30 meters

Li-Po battery: 3.7v 220MAH Li-poly for helis

Battery for controller: 4*"AAA"batteries(not included)

Double Protection: Helicopter flies more safely, as it will power off automatically when choked.

Material:PA,ALLOY

Package Included

1 × Helicopter

1 × Transmitter

1 × USB Cable

1 × CD Disk with instruction

1 × A Blade

1 × B Blade

1 × Tail Blade

[**Click to learn more about us.**](#)

