

# Wltoys V303 2.4G GPS RC Quadcopter Arayıcı quadcopter

## Ürün Fonksiyonlar

1. GPS Oto Pilot Fonksiyonu.
2. Uçuş Kontrol Kurulu Denetim GPS Yükseklik.
3. CF Başkanı serbest modu (Genellikle, bir uçan çok rotor ileri yön burun yönü aynıdır. Yerde burun noktaları, ileri yön burun yönü ile ilgisi yoktur, Akıllı Yön Kontrolü (IOC) kullanarak : ders kilit Uçma da, ileri yön kaydedilmiş bir burun yönü ile aynıdır ana kilit olarak ileri doğru çoklu rotora giriş noktasından yönü ile aynıdır, uçan).. (DJI Phantom (720P & amp Video Kamera gibi Benzer 2.4G Otomatik Pathfinder UVA; 1080P eklenebilir).) 4. One Key Go Home
5. Hatasız & amp; Ana Denetleyici ve verici arasındaki iletişim kesildiğinde otomatik go home / iniş (kontrolör tüm komuta sopalarla çıkışları merkez konumuna gidecek., GPS sinyal yeterince iyi ise, sistem otomatik olarak evine dönmek tetikleyecek ve güvenli ineceğim.)
6. alçak gerilim iki düzeyde koruma (koruma İlk aşamada, LED gösterge otomatik dönüş fonksiyonunu tetikleyecek koruma sisteminin ikinci katmanında. Sizi uyarmak için kırmızı renkte yanıp söner.)

# QUADROCOPTER SEEKER

GPS POSITIONING

AUTOMATIC RETURN

SUPPORT FOR EXTERNAL PTZ IMAGE PICKUP

OUT OF CONTROL AND RETURNING FUNCTION

OPERATING FREQUENCY 2.4GHZ







**FIXED POINT AND HEIGHT  
WITHOUT CONTROLLING**






## HEADING LOCK MODE

Open the heading lock switch the headless mode is turned on

## AUTO-RETURN FUNCTION

When the explorer beyond the range, the system automatically start its protection function protection aircraft safely return



AUTO-RETURN



AUTO-RETURN BY CLOSING THE REMOTE CONTROL



SUPER CAPACITY BATTERY



POWERFUL MOTOR



FLASHING LAMP



## BASIC PARTS LIST



QUADROCOPTER SEEKEY



TRANSMITTER



PROPELLER



PLUG



USB DATA CABLE



BATTERY



CHARGER



CAMERA ( IN ADDITION TO BUY )



OTHER PARTS



CAMERA FRAME

## PRODUCT DETAILS



**ADVANCED MATERIAL**



**PROPELLER**



**UNIQUE APPEARANCE**



**SKID LANDING GEAR**



**FLASH LED**



**MICRO-CAMERA**

**OUTDOOR SENCE**



**QUADROCOPTER SEEKEY**





## PRODUCT STRUCTURE



PROPELLER

USB SOCKET

FUSELAGE ABDOMINAL

WIFI SOCKET

LED FLYING INDICATOR

MAGNETIC SENSOR

▲  
BOTTOM



## REMOTE CONTROL INSTRUCTION



### RC BATTERY BOX

Put the 4 batteries into the battery box in the correct way, and then cover the battery cover.

## ASSEMBLY INSTRUCTIONS

### INSTALL THE BLADES



**STEP 1** Take down the propeller hoop on the motor first



**STEP 2** Make sure the rotating direction of the blades should be the same as the rotating direction of the motor



**STEP 3** Put the propeller hoop on the blade



**STEP 4** Insert one round stick into the hole of the propeller hoop, Reverse rotation arrow

## INSTALL THE BATTERY



**STEP 1** Hold the battery cover and pull out



**STEP 2** Put the battery into battery compartments



**STEP 3** Connect the battery and the power wires



**STEP 4** Cover the battery cover

## INSTALL THE CAMERA



**GOPRO 3 CAMERA**  
NEED TO BUY IT BY YOURSELF

IT CAN NOT BE LOADED ANY OTHER  
CAMERAS IN THE MARKET

## THE INSTALLATION OF THE CAMERA FRAMES



## INSTALL THE CAMERA FRAME TO THE BOTTOM OF THE AIRCRAFT



## INSTALL THE CAMERA TO THE CAMERA FRAME



## Özellikler

Ürün Pil: 11.1V 2700mAh 25C (dahil),  
Radyo Pil: 6 \* 1.5AA (dahil değil)  
Motor: 2212 950 / KV×4adet  
Verici Mesafe: 500 metre  
Süresi Şarj: 1.5-2hours  
Zaman Playing: 13-15Mins

## Paket listesi

- 1 × Quadcopter
- 1 × Renk bo
- 1 × Radyo
- 1 × Manuel
- 1 × Dengesi Şarj
- 4 × Bıçak
- 1 × Lipo pil
- 1 × USB
- 1 × Hex Anahtarı
- 1 × Gimble (GOPRO Kamera Montaj)

**[Hakkımızda daha fazla bilgi edinmek için tıklayın.](#)**

**MORE PRODUCTS!**